


Fender®


JAZZ BASS® (P/N 18-0200)



Ref	Part Number	Description
1	010144 000	Neck, Maple, w/Hardware (Tilt)
1	010143 000	Neck, Rswd, w/Hardware (Tilt)
2	010149 000	Pickguard, (Black)
2	015578 000	Screw, Pickguard/String Guide
3	010660 090	Pick-Up Cover (Chrome)
3	033753 000	Pick-Up, Rhythm
3	016915 000	Pick-Up Cover (Plastic)
4	013366 000	Volume Knob
5	013364 000	Tone Knob
6	010652 060	Control Plate (Chrome)
7	021956 000	Phone Jack
7	016352 000	Hex Nut, Phone Jack/Controls
7	016436 000	Washer, Phone Jack/Controls
8	010678 100	Bridge Cover (Chrome)
8	018606 000	Rubber Mute—Bridge Cover
9	033746 000	Pick-Up, Lead
9	016923 000	Pick-Up Cover (Plastic)
10	010139 000	Body, All Finishes (Tilt)
11	018614 000	Thumb Rest
11	015610 000	Screw, Base Plate/Thumb Rest
12	012344 000	Strap Button
12	016188 000	Screw, Strap Button
13	083675 000	Bone Nut (Neck)
14	010286 000	Nut, Truss Rod (Bullet)
15	013187 000	Patent Head (Keys)
15	013188 000	Bushing, Patent Head
15	011357 000	Screw, Patent Head
16	013235 000	String Guide (Neck)

JAZZ BASS®

(BRIDGES AND CONTROLS)



Ref	Part Number	Description
17	018689 000	Spring, Bridge Bar
18	010538 070	Bridge Base Plate
19	011751 000	Screw, Height Adj. (Bridge)
20	007706 000	Bridge Bar
21	015842 000	Screw, Length Adj. — Bridge
22	013446 000	Tone & Volume Control
23	013472 000	Capacitor (.022 X 200V)

ITEMS NOT REFERENCED

Part Number	Description
010686 020	Pick-Up Shield
011100 000	Neck Plate Gasket
015636 000	Screw, Neck Mounting
016287 000	Screw, Pick-Up
039883 000	Bridge Assembly
040113 000	Control Plate Assembly

